


Log Set Assembly



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.




**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Set Assembly		SRV4055-077	Y
1	Log 1 (Back Log)		4055-080	
2	Log 2 (Left Log)		4055-084	
3	Log 3 (Top Log)		4055-083	
4	Log 4 (Right Log)		4055-087	
5	Intake Cover Plate		25844	
6	Intake Cover Gasket		4031-239	
7	Not replaceable must order overlay		4055-194	
8			4055-133	
9	Glass Latch Assembly	Qty 4 req	33858	Y
10	Dry Wall Lip		4031-205	
11	Flue Visor		4031-119	
12	Glass Shield		4031-217	
13	Hearth Pan		4055-109	
14	Burner Assembly		4055-046	Y
15	Valve Assembly		4055-025	
16	Gasket, Valve Plate		4055-135	
17	Glass Frame Assembly		4031-539	Y
18	Hood		4055-213	
19	Screen Assembly		SRV4055-929	Y
20	Floor Cover		4055-272	
21	Magnetic Touch Latch	Qty 2 req	4021-650	
22	Junction box		4021-013	Y
23	Cover Plate		4031-222	
24	Not replaceable must order overlay		4055-194	
25			4055-133	
26	Shield Junction Box		4031-193	
27	Nailing Flange	Qty 4 req	4044-161	
28	Back Gasket		4000-225	
	Lava Rock Bag Assembly		4040-094	
	Screen Rod		4055-614	Y
	Conversion Kit NG		SCKVN-B	Y
	Conversion Kit LP		SCKVP-B	Y
	Pilot Orifice NG		29476	Y
	Pilot Orifice LP		29477	Y
	Regulator NG		230-1570	Y
	Regulator LP		230-1520	Y

Additional service part numbers appear on following page.

Standing Pilot Valve Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	Stocked at Depot
1	Pilot Assembly NG		2103-010	Y
	Pilot Assembly LP		2103-011	Y
2	Gasket, Pilot		4021-042	
3	Air Shutter Assembly		4055-202	Y
4	Bracket, Valve		4055-205	
5	Piezo Ignitor		291-513	Y
6	Flex Ball Valve Assembly		302-320A	Y
7	Valve NG		230-0710	Y
	Valve LP		230-0720	Y
8	Brass Fitting	Pkg of 5	303-315/5	Y
9	Gasket, Bulkhead		4021-429	
10	Bulkhead, Flexible		4021-512	Y
	Wire Assembly, Wall Switch		28602	Y
	Orifice NG (.083)		4021-435	Y
	Orifice LP (# 52C)		4021-426	Y